

**CombiView**

**MX880053A  
FM/Audio Application Applet  
Operation Manual**

# Safety Symbols

To prevent the risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Ensure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following symbols may be used on all Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in this manual.

## Symbols used in manual



### **DANGER**

This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.



### **WARNING**

This indicates a hazardous procedure that could result in serious injury or death if not performed properly.



### **CAUTION**

This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction, if proper precautions are not taken.

## Safety Symbols Used on Equipment and in Manual

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment.



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates a warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

MX880053A

FM/Audio Application Applet  
Operation Manual

18 December 2012 (First Edition)

30 November 2015 (Fifth Edition)

Copyright © 2012-2015, ANRITSU CORPORATION.

All rights reserved. No part of this manual may be reproduced without the prior written permission of the publisher.

The contents of this manual may be changed without prior notice.

Printed in Japan

## **Equipment Certificate**

Anritsu Corporation guarantees that this equipment was inspected at shipment and meets the published specifications.

## **Anritsu Warranty**

- During the warranty period, Anritsu Corporation will repair or exchange this software free-of-charge if it proves defective when used as described in the operation manual.
- The warranty period is 6 months from the purchase date.
- The warranty period after repair or exchange will remain 6 months from the original purchase date, or 30 days from the date of repair or exchange, depending on whichever is longer.
- This warranty does not cover damage to this software caused by Acts of God, natural disasters, and misuse or mishandling by the customer.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation shall assume no liability for injury or financial loss of the customer due to the use of or a failure to be able to use this equipment.

## **Anritsu Corporation Contact**

In the event of this equipment malfunctions, contact an Anritsu Service and Sales office.

Contact information is available in a separate file (for the PDF version), and on the last page of this manual (for the printed version).

### Notes On Export Management

---

This product and its manuals may require an Export License/Approval by the Government of the product's country of origin for re-export from your country.

Before re-exporting the product or manuals, please contact us to confirm whether they are export-controlled items or not.

When you dispose of export-controlled items, the products/manuals need to be broken/shredded so as not to be unlawfully used for military purpose.

# Software End-User License Agreement (EULA)

Please read this Software End-User License Agreement (hereafter this EULA) carefully before using (includes executing, copying, registering, etc.) this software (includes programs, databases, scenarios, etc., used to operate, set, etc., Anritsu electronic equipment). By reading this EULA and using this software, you are agreeing to be bound by the terms of its contents and Anritsu Corporation (hereafter Anritsu) hereby grants you the right to use this Software with the Anritsu-specified equipment (hereafter Equipment) for the purposes set out in this EULA.

## 1. Grant of License and Limitations

1. Regardless of whether this Software was purchased from or provided free-of-charge by Anritsu, you agree not to rent, lease, lend, or otherwise distribute this Software to third parties and further agree not to disassemble, recompile, reverse engineer, modify, or create derivative works of this Software.
2. You may make one copy of this Software for backup purposes only.
3. You are not permitted to reverse engineer this software.
4. This EULA allows you to install one copy of this Software on one piece of Equipment.

## 2. Disclaimers

To the extent not prohibited by law, in no event shall Anritsu be liable for personal injury, or any incidental, special, indirect or consequential damages whatsoever, including, without limitation, damages for loss of profits, loss of data, business interruption or any other commercial damages or losses, arising out of or related to your use or inability to use this Software.

## 3. Limitation of Liability

- a. If a fault (bug) is discovered in this Software, preventing operation as described in the operation manual or specifications whether or not the customer uses this software as described in the manual, Anritsu shall at its own discretion, fix the bug, or exchange the software, or suggest a workaround, free-of-charge. However, notwithstanding the above, the following items shall be excluded from repair and warranty.
  - i) If this Software is deemed to be used for purposes not described in the operation manual or specifications.
  - ii) If this Software is used in conjunction with other non-Anritsu-approved software.
  - iii) Recovery of lost or damaged data.
  - iv) If this Software or the Equipment has been modified, repaired, or otherwise altered without Anritsu's prior approval.
  - v) For any other reasons out of Anritsu's direct control and responsibility, such as but not limited to, natural disasters, software virus infections, etc.
- b. Expenses incurred for transport, hotel, daily allowance, etc., for on-site repairs by Anritsu engineers necessitated by the above faults shall be borne by you.
- c. The warranty period for faults listed in article 3a above covered by this EULA shall be either 6 months from the date of purchase of this Software or 30 days after the date of repair, whichever is longer.

#### **4. Export Restrictions**

You may not use or otherwise export or re-export directly or indirectly this Software except as authorized by Japanese and United States law. In particular, this software may not be exported or re-exported (a) into any Japanese or US embargoed countries or (b) to anyone on the Japanese or US Treasury Department's list of Specially Designated Nationals or the US Department of Commerce Denied Persons List or Entity List. By using this Software, you warrant that you are not located in any such country or on any such list. You also agree that you will not use this Software for any purposes prohibited by Japanese and US law, including, without limitation, the development, design and manufacture or production of missiles or nuclear, chemical or biological weapons of mass destruction.

#### **5. Termination**

Anritsu shall deem this EULA terminated if you violate any conditions described herein. This EULA shall also be terminated if the conditions herein cannot be continued for any good reason, such as violation of copyrights, patents, or other laws and ordinances.

#### **6. Reparations**

If Anritsu suffers any loss, financial or otherwise, due to your violation of the terms of this EULA, Anritsu shall have the right to seek proportional damages from you.

#### **7. Responsibility after Termination**

Upon termination of this EULA in accordance with item 5, you shall cease all use of this Software immediately and shall as directed by Anritsu either destroy or return this Software and any backup copies, full or partial, to Anritsu.

#### **8. Dispute Resolution**

If matters of dispute or items not covered by this EULA arise, they shall be resolved by negotiations in good faith between you and Anritsu.

#### **9. Court of Jurisdiction**

This EULA shall be interpreted in accordance with Japanese law and any disputes that cannot be resolved by negotiation described in Article 8 shall be settled by the Japanese courts.

## Protection Against Computer Virus Infections

---

Prior to the software installation

Before installing this software or any other software recommended or approved by Anritsu, run a virus scan on your computer, including removable media (e.g. USB memory stick and CF memory card) you want to connect to your computer.

When using this software and connecting with the measuring instrument

- Copying files and data

On your computer, do not save any copies other than the following:

- Files and data provided by Anritsu
- Files created by this software
- Files specified in this document

Before copying these files and/or data, run a virus scan, including removable media (e.g. USB memory stick and CF memory card).

- Connecting to network

Connect your computer to the network that provides adequate protection against computer viruses.

## Cautions on Proper Operation of Software

---

This software may not operate normally if any of the following operations are performed on your computer:

- Simultaneously running any software other than that recommended or approved by Anritsu
- Closing the lid (Laptop computer)
- Turning on the screen saver function
- Turning on the battery-power saving function (Laptop computer)

For how to turn off the functions, refer to the operation manual that came with your computer.

# CE Conformity Marking

Anritsu affixes the CE conformity marking on the following product(s) in accordance with the Council Directive 93/68/EEC to indicate that they conform to the EMC and LVD directive of the European Union (EU).

## CE marking



### 1. Product Model

Software: MX880053A FM/Audio Application Applet

### 2. Applied Directive and Standards

When the MX880053A FM/Audio Application Applet is installed in the MT8870A, the applied directive and standards of this software conform to that of the MT8870A main frame.

PS: About main frame

Contact Anritsu for the latest information about main frame types supporting the MX880053A FM/Audio Application Applet.



# C-tick Conformity Marking

Anritsu affixes the C-Tick mark on the following product(s) in accordance with the regulation to indicate that they conform to the EMC framework of Australia/New Zealand.

## C-tick marking



### 1. Product Model

Software: MX880053A FM/Audio Application Applet

### 2. Applied Directive and Standards

When the MX880053A FM/Audio Application Applet is installed in the MT8870A, the applied directive and standards of this software conform to that of the MT8870A main frame.

PS: About main frame

Contact Anritsu for the latest information about main frame types supporting the MX880053A FM/Audio Application Applet.




# About This Manual


---

This manual mainly describes the operation of the MX880053A FM/Audio Application Applet.

Products relevant to the MT8870A Universal Wireless Test Set include:

- MT8870A Universal Wireless Test Set (main unit)
- Modules installed in the MT8870A
- Application software installed in modules
- Control software installed in external PC controller

These products are called the Universal Wireless Test Set Series. The operation manuals for the Universal Wireless Test Set Series consist of separate documents for the main unit, module(s), application software, and control software as listed below.  indicates this manual.



# Contents

---

About This Manual .....	I
-------------------------	---

Chapter 1 Overview .....	1-1
--------------------------	-----

1.1 CombiView Introduction .....	1-1
1.2 Composition .....	1-6

Chapter 2 Before Use .....	2-1
----------------------------	-----

2.1 Operating Environment .....	2-1
2.2 Connecting to MT8870A .....	2-4
2.3 Installing and Uninstalling MX880053A .....	2-5
2.4 Starting and Stopping CombiView .....	2-6
2.5 Names of CombiView Screens Elements .....	2-9

Chapter 3 Operation .....	3-1
---------------------------	-----


3.1 Basic Operations .....	3-1
3.2 Common Settings .....	3-10
3.3 FM Transmitter Measurement .....	3-12
3.4 FM Receiver Measurement .....	3-22
3.5 Audio Signal Measurement .....	3-28
3.6 Audio Signal Transmission .....	3-35

# Chapter 1 — Overview

## 1.1 CombiView Introduction

CombiView is PC application software for the external Control PC used to control the MT8870A Universal Wireless Test Set (hereafter MT8870A).

CombiView allows the user to configure measurements and display results.



**Figure 1.1-1** Ethernet Connection between Control PC and MT8870A

The CombiView application:

- Supports measurement using the MT8870A without creating remote control programs.
- Automatically detects application software registered in the MT8870A.
- Runs in the Windows 7 and Windows XP OS environments.
- Supports remote control over Ethernet (IPv4) and GPIB.
- Supports multiple measurement standards with additional Applets.


CombiView supports the following Applets.

**Table 1.1-1** CombiView Applets


Model/Code	Product Name
MX880051A	Cellular Application Applet
MX880052A	SRW Application Applet
MX880053A	FM/Audio Application Applet
MX880054A	Signal Generator Application Applet
MX880055A	Small Cell Application Applet
MX880056A	IEEE802.15.4 Application Applet

The MX880053A FM/Audio Application Applet (hereafter MX880053A) adds application measurement functions to CombiView.

The six CombiView applets and the optional applications that each applet supports are shown in the figure below. This manual provides information on the area enclosed by the dotted line.



**Figure 1.1-2** CombiView Applets and Associated MT8870A Applications Options (1/2)



**Figure 1.1-3** CombiView Applets and Associated MT8870A Applications Options (2/2)

At least one of following application software licenses must be registered in the MT8870A to control it using the MX880053A. Additionally, the MU887000A-002/102 Audio Measurement Hardware is required to measure and transmit audio signals.

**Table 1.1-2** Application Software Licenses Required by MT8870A

Model/Code	Product Name
MX887070A	FM/Audio TRX Measurement



An example of the MX880053A screen is shown below. A parameter setting dialog box is displayed when a setting item in the left frame is clicked. The measurement results are displayed in the right frame.




Figure 1.1-4 MX880053A Screen




Figure 1.1-5 Parameter Setting Screen

## 1.2 Composition

The MX880053A composition is listed in the following table.

The electronic files are stored in one or more storage media (DVD, etc.)

**Table 1.2-1** Composition

Model/Code	Product Name	Remarks
MX880053A	FM/Audio Application Applet	—
W3659AE	MX880053A FM/Audio Application Applet Operation Manual	English

## Chapter 2 — Before Use

This chapter explains how to start the MX880053A.

### 2.1 Operating Environment

This section describes the MX880053A operating environment.

**Table 2.1-1** Operating Environment

Item	Specification
OS	Windows XP Professional Service Pack 3, Japanese/English* <sup>1</sup> Windows 7 Service Pack 1, Japanese/English
Display	Resolution: 1024 × 768 or better
Memory	Capacity: ≥1 GB
Hard disk free space	≥200 MB * <sup>2</sup>
VISA	NI-VISA* <sup>3</sup>
.NET Framework	.NET Framework 4.0 (Full set version) or .NET Framework 4.5

\*1: If Windows XP Professional Service Pack 3 is applied, be sure to update it using Windows Update.

\*2: This is the free space required by the CombiView software. More free space is required to install VISA and .NET Framework.

\*3: For version compatibility among OS, .NET Framework, and NI-VISA, refer to Table 2.1-2 and Table 2.1-3.

**Table 2.1-2** Compatibility Table of OS and .NET Framework

OS	.NET Framework 4.0	.NET Framework 4.5
Windows XP	✓	—
Windows 7	✓	✓

✓: Compatible    —: Incompatible

**Table 2.1-3** Compatibility Table of .NET Framework and NI-VISA

NET Framework	NI-VISA 5.0.3 to 5.2	NI-VISA 5.3 to 14.0
.NET Framework 4.0	✓	✓
.NET Framework 4.5	—	✓

✓: Compatible    —: Incompatible

**Table 2.1-4** NI-VISA Version

CombiView Package Version	NI-VISA Version
Ver 01.06.01 or older	Version 5.03 to Version 5.4
Ver 01.07.00 or later	Version 5.03 to Version 5.4.1, and Version 14.0

For package version compatibility with CombiView and cellular applet, refer to Table 2.1-5. They may not function properly in combinations that are not shown in the table.

**Table 2.1-5** Package Version Compatibility


Package	CombiView	FM/Audio Applet
Ver 01.02.08	1.2.4702.26073	1.2.8.0
Ver 01.03.04	1.2.4821.28484	1.3.1.0
Ver 01.04.15	1.4.1.0	1.3.1.0
Ver 01.04.16	1.4.3.0	1.3.1.0
Ver 01.06.01	1.4.3.0	1.3.1.0
Ver 01.07.00	1.6.2.0	1.4.0.0
Ver 01.07.09	1.6.10.0	1.4.1.0

For package versions compatible with a module to be used, refer to Table 2.1-6.

**Table 2.1-6** Version Compatibility

Module	Package
MU887000A	All version
MU887001A	Ver 01.04.16 or later

To use the package of Ver 01.06.01 or earlier, select [.NET Framework 4.0 Languages Support] at NI-VISA installation.



**Figure 2.1-1** Selecting .NET Framework4.0 Languages Support

## 2.2 Connecting to MT8870A

Connect the Control PC having CombiView installed on it to the MT8870A. Refer to section 2.5 Connecting Cables in the MT8870A Universal Wireless Test Set Operation Manual.

CombiView detects connected instruments automatically. It is not necessary to set the IP address or GPIB address of connected instruments.

### 2.2.1 Connecting Ethernet cable

Use an Ethernet cable that is category-5 or better and straight-through.

1. Connect the Ethernet cable to the Control PC.
2. Connect the other end of the Ethernet cable to the Ethernet connector on the front or rear panel of MT8870A.




Figure 2.2.1-1 Connecting to Front Ethernet Connector




Figure 2.2.1-2 Connecting to Rear Ethernet Connector

### 2.2.2 Connecting GPIB cables

Option 001/101 adds GPIB connectors for each module to the MT8870A rear panel. Connectors 1 to 4 correspond to slots 1 to 4. A GPIB interface must also be added to the Control PC. The operation of CombiView over the National Instruments GPIB interface has been verified by Anritsu.

1. Connect a GPIB cable to the GPIB interface added to the Control PC.
2. Connect the other end of the GPIB cable to the GPIB connector on the MT8870A rear panel.

## 2.3 Installing and Uninstalling MX880053A

### 2.3.1 Installing

To install the MX880053A, run the installation file on the storage media as follows:

1. Open the /Installer/CombiView folder on the storage media.
2. Double-click **CombiViewSetup.msi**.
3. Follow the instructions displayed by the installation dialog.
4. Double-click **CombiView.MT8870x.FMAudio.Installer.msi**.
5. Follow the instructions displayed by the installation dialog.

### 2.3.2 Uninstalling

1. When using Windows XP: At the Windows Control Panel, click **Add or Remove Programs**, and then double-click **MX880053A CombiView FMAudio Applet** in the list of **Remove or Change Programs**.

When using Windows 7: At the Windows Control Panel, click **Programs and Features**, and then double-click **MX880053A CombiView FMAudio Applet** in the list of **Uninstall or change program**.

2. When you are asked if you really want to uninstall the MX880053A, click **Yes** to uninstall it.
3. Similarly as step2, uninstall Anritsu CombiView.


## 2.4 Starting and Stopping CombiView

### Starting CombiView

When using Windows XP, start CombiView at the Control PC by clicking **Start Menu > Programs > Anritsu > CombiView > CombiView**.

When using Windows 7, start CombiView at the Control PC by clicking **Start > All Programs > Anritsu > CombiView > CombiView**.

When CombiView is launched, the **Instrument Connection Options** dialog box is displayed.



**Figure 2.4-1** Instrument Connection Options Dialog Box




In the selected search mode, CombiView searches for MT8870As in the network.

**Table 2.4-1 Search Mode for MT8870As**

Name	Description
Search for Instruments	Searches for all MT8870As existing in the selected network.
Use Known Instruments	Searches for MT8870As to which the modules with IP addresses specified are installed.
Simulation Mode	Places CombiView offline (the state where there is no communication with connected instruments) without searching for MT8870As.

To edit the IP addresses of known MT8870As, click **Use Known Instruments**, and then click **Edit**.




**Figure 2.4-2 Known Instruments Dialog Box**

To add a known MT8870A, click **Add**, and then enter its IP address. To delete an MT8870A from the list, select it, and then click **Remove**.

**Note:**

Multiple instances of CombiView cannot be started simultaneously. The following message is displayed if CombiView is already running.



**Figure 2.4-3 Message when CombiView is running**

## Stopping CombiView

Click the **Close** button at the top right corner of the window.




**Figure 2.4-4** Close Button

**Note:**

When the MX880053A stops, the MT8870A remote command language is the SCPI mode. To change to the Native language mode, send the `:SYST:LANG NAV` command.

## 2.5 Names of CombiView Screens Elements


This section names each part of the CombiView screens.



**Figure 2.5-1** CombiView Manager Screen

**Table 2.5-1** Menu of CombiView Manager Screen

Name	Description
Tools	
Update Connection Options	Opens the <b>Instrument Connection Options</b> dialog box to search for MT8870As again in the network.
MT8870A-Utility tool	Starts the MX887900A Utility Tool
Help	
About	Displays information about hardware and applets


**Figure 2.5-2** CombiView Screen

The width of the Settings pane can be adjusted by dragging the vertical bar that separates the Settings pane from the results display area.

**Table 2.5-2** Menus of CombiView Screen

Name	Description
File	
Load Settings	Load the settings pane information from a file.
Save Settings	Save the settings pane information to a file.
Save Settings as...	Save the settings pane information to a file specifying the name.
Exit	Closes the CombiView screen
Path Loss	
Configure Correction...	Sets a correction value for power loss of each port.
Apply Correction	Applies the parameter value set by Configure Correction...
Window	
Tile Horizontal	Arranges multiple result tabs in a vertical stack.
Tile Vertical	Arranges multiple result tabs side by side.
Reset Window Layout	Releases the result tab display in order.
Help	
About	Displays information about MX880053A

Click **Configure Correction** to display the window below. This window allows setting a power loss value from cable, etc. Adding lines to the table enables settings for multiple measurement frequencies.




**Figure 2.5-3 Configure Path Loss Correction Screen**

**Table 2.5-3 Configure Path Loss Correction Screen Menu**

Name	Description
Load from File...	Loads settings from a Path Loss parameter file to the table.
Save to File...	Saves the Path Loss setting parameters in csv format.
Table	Changes the table to set Path Loss. Up to 16 tables can be created.
Add Entry	Adds new lines.
Delete Entry	Deletes the selected lines.
Send to Instrument	Sends the Path Loss settings to the MU887000A.
Done	Ends Path Loss Configure Correction.


Select the Apply Correction check box to apply the Path Loss setting. This function is the same as **Apply Correction** in the CombiView menu.

When trying to change a table or close Configure Pass Loss Correction without sending the edited parameters to the MU887000A, the message below is displayed.



**Figure 2.5-4** Transfer Table? Message

When selecting **Yes**, the specified parameter is sent to the MU887000A. When selecting **No**, the parameter is not sent to the MU887000A, but the parameters set for the table is deleted.



**Figure 2.5-5** Tab Selection

If many graphs are selected, one or two tabs may not appear on the screen. In that case, tabs to display can be selected from the list by clicking the tab selection.


# Chapter 3 — Operation

This chapter describes basic operation of the MX880053A, as well as the items displayed at each measurement.


## 3.1 Basic Operations

### 3.1.1 Selecting measurement Items


When CombiView is started, the **CombiView Manager** tree view screen displays information about the detected hardware (MT8870A).



**Figure 3.1.1-1** Tree View

1. Click . If FM Audio appears in the tree view, the measurement conditions can be set and the results can be displayed on the MX880053A.

Uninstalled applications are also shown in the tree view. Attempting to start an uninstalled application displays an alert dialog.


2. Click the  **Refresh** button to update the display.
3. Double-click the name of the application to start.
4. Establishing communications with the MT8870A may require several seconds before the **CombiView** screen opens.

The MT8870A setting parameters are displayed in the settings pane.

### 3.1.2 Operations at measurement settings pane

#### Measurement settings pane

The measurement settings pane consists of text boxes and buttons to set measurement parameters.



**Figure 3.1.2-1** Measurement Settings Pane

The contents of the measurement settings pane vary with the measurement item, but the following buttons are always displayed.

**Table 3.1.2-1** Measurement Settings Pane Buttons

Name	Description
Display Results	Displays numerical measurement results.
Common Setting	Sets the RF port, audio port, and measurement type of the MU887000A.
TX-FM	Set the parameters for FM transmitter measurement.
TX-Audio	Sets the parameters for audio signal measurement.
RX-FM	Sets the parameters for FM receiver measurement.
Vector Signal Generator	Sets the MU887000A output signal.
RX-Audio(Analog)	Sets the output signal to audio port (analog).
RX-Audio(Digital)	Sets the output signal to audio port (digital).
Display Results Settings	Displays measurement results.
Graph: FM RF Spectrum Monitor	Sets the graph view of FM transmitter measurement on the spectrum monitor.
Graph: FM Demod-AF	Sets the graph view of the demodulated signal of FM receiver measurement.
Graph: Audio AF(Analog)	Sets the graph view of audio signal measurement (analog).
Graph: Audio AF(Digital)	Sets the graph view of audio signal measurement (digital).
Level Calibration	Executes calibration of the MU887000A. Calibration type can be selected before executing.
Test Command	Sends the input command.

Click the Open/Close button to display the hidden setting items.






---

Starting/stopping measurement

To start or stop measurement, click the following buttons.

**Table 3.1.2-2** Measurement Start/Stop Buttons

Button	Name	Behavior
	Measurement Start Button	Starts and executes one measurement
	Continuous Measurement Start Button	Repeats measurement until Stop button click
	Measurement Stop Button	Stops measurement

The status indication lamp 3 of MU887000A is on during the execution of measurement.

When the measurement error occurs, the status indication lamp 3 of MU887000A is lit in red.


In that case, query the cause by using :FETCh:FMAudio:MEASurement:STATe? command.


For the command explanation, refer to Chapter 3 “SCPI Command Reference” in *the MX887070A FM/Audio TRX Measurement Operation Manual*

#### Measurement results display


Click the **Display Results** button at the measurement settings pane to display numeric data.

#### Graph display

To display the graph, click the check icon  on the settings pane before starting measurement.


When the check icon is enabled (changed to dark gray), the MX880053A reads the waveform data after the measurement. Click the graph icon  on the settings pane to display the graph tab.

Dragging this tab displays the result in a separate floating window.



**Figure 3.1.2-2** Floating Window

To move the floating window back to its original position, click the ▼ button in the top right corner of the window to display a pull-down menu and click the **Dock** button in the menu.



**Figure 3.1.2-3** Floating Window Pull-Down Menu

To close the measurement results display, click the **×** button at the measurement results tab or at the top right of the floating window.

When drag the measurement results tab, a cross-like icon appears at the center of the screen. Drag the tab onto one of the four squares of the icon to display the measurement results in split sections.



Figure 3.1.2-4 Example of Split Window

To restore the original display, drag the split windows onto the center square of the cross-like icon.





Figure 3.1.2-5 Cancel Window Split

## Save Graph and Print Graph

**Figure 3.1.2-6** Save Graph and Print Graph

Right-click on the graph to display the popup menu.


Click the **Save Graph Data...** to show folder selecting dialog box.

Select folder to save and input file name, then click **OK**.

Click the **Print Graph Image...** to show print dialog box.

Select the printer and print format, then click **Print**.

### Error messages

If set parameters have an error, an error message is displayed when clicking the Measurement Start button  or **Apply**.

For the details of the error message, refer to the description of “:SYSTem:ERRor” command in *the MU887000A TRX Test Module Operation Manual*.


### 3.1.3 Sending commands

To execute other commands not provided in the measurement settings pane and query the MU887000A status:

1. Click the **Test Command** button on the measurement settings pane to open the **Test Command** dialog.
2. Input the command in the **Command/Query** text box.
3. Click the **Send** button. When Query is sent, the response is displayed in the **Query Response** text box.

**Notes:**

- The MX880053A communicates with the MT8870A in SCPI command Mode. Sending the Native Command causes an error.
- An error code and error message pop up when the sent command is not correct. An error code and error message appear in the Query Response field when the sent command is not correct.  
For details of ErrorCode-format messages, refer to the description of the :SYSTem:ERRor? command in the MU887000A TRX Test Module Operation Manual.
- Do not switch the language mode of remote control commands. If the language mode is switched, a command error occurs in subsequent applet operations.



**Figure 3.1.3-1** Test Command Dialog


If the sent command is not correct, the status lamp of the MU887000A blinks. For the explanation of the status lamp, refer to Appendix D “Status Indication of lamps” in *the MU887000A TRX Test Module Operation Manual*.

## 3.2 Common Settings

This section explains the setting items common in Section 3.3 “FM Transmitter Measurement” through Section 3.6 “Audio Signal Measurement.”

### 3.2.1 Setting conditions

The figure below is the settings pane for FM transmitter measurement. Change the parameter values or selections by clicking ▲/▼.



**Figure 3.2.1-1** Common Setting Pane


The following items are changed in view depending on the DUT Type setting and the presence of the MU887000A-002/102.

Test Set Role – Audio Port, Test Set Role – RF Test Port




### 3.2.2 Related SCPI commands

The following figure shows the remote control commands of the MX887070A FM/Audio TRX Measurement and the corresponding fields on the pane. For details of the commands, refer to Chapter 3 “SCPI Command Reference” in *the MX887070A FM/Audio TRX Measurement Operation Manual*.



**Figure 3.2.2-1** Measurement Settings Pane (Common Setting)



**Figure 3.2.2-2** Measurement Settings Pane (Level Calibration)


## 3.3 FM Transmitter Measurement

This section explains how to perform FM transmitter measurement.

### 3.3.1 Setting conditions






The figure below is the settings pane for FM transmitter measurement.



Change the parameter values or selections by clicking ▲/▼.

**Figure 3.3.1-1** FM Transmitter Measurement

**3.3.2 Measurement and results**

To perform measurement:


1. Click the Open/Close button to open [Common Setting] and set DUT Type to [FM Transmitter].
2. Set the parameters of [Common Setting].
3. Click the Open/Close button of [TX-FM], and set the parameters from [Frequency (MHz)] to [Audio Modulation].
4. When [Audio Modulation] is set to [Stereo], open [Left-Channel] and [Right-Channel] by clicking the Open/Close buttons and set the parameters.
5. Set [RDS Analysis].
6. Click the Open/Close button of [Graph: FM RF Spectrum Monitor] and enables the check icon .  
Also, set [FM RF Spectrum Monitor Frequency Span(kHz)].
7. Open [Graph: FM Demod-AF] by clicking the Open/Close button, and enable the check icon of [Time Domain (FM) ], [Time Domain (Left) ], [Time Domain (Right) ], [Spectrum Monitor (Left)], or [Spectrum Monitor (Right)].  
Additionally, set the parameters from [Time Domain X-Axis Range(ms)] to [Spectrum Monitor Y-Axis Scale (Right) (dB)].
8. Click [Display Results] to display [FM Audio] tab.
9. Click the Open/Close button to open [Display Results Settings], and select the [TX-FM] check icon .
10. Click the Measurement Start button  to send the parameters to the hardware.
11. When the measurement ends, numerical data is displayed in TX-FM on [FM Audio] tab.
12. Click the graph icon  on the next pane to display the graph tab.  
[Graph: FM RF Spectrum Monitor], [Graph: FM Demod-AF]
13. To display the marker positions and values, click  button in [Makers] sub window on the top-right corner. When dragging the markers, the positions are shown by values in the sub window.

**Figure 3.3.2-1** Spectrum Monitor Graph**Figure 3.3.2-2** Time Waveform Graph of Demodulated Signal


### 3.3.3 Related SCPI commands

The figure below shows the remote control commands for the MX887070A FM/Audio transmission measurement and the corresponding fields on the pane.

For details of the commands, refer to Chapter 3 “SCPI Command Reference” in *the MX887070A FM/Audio TRX Measurement Operation Manual*.




**Figure 3.3.3-1** Measurement Settings Pane (TX-FM)



:FETCh:FMAudio:FM:RF:TRACe:BINary

**Figure 3.3.3-2** Measurement Settings Pane (Graph FM RF Spectrum Monitor)



:FETCh:FMAudio:FM:AUDio:TIME:TRACe:BOTH:BINary

:FETCh:FMAudio:FM:AUDio:TIME:TRACe:LEFT:BINary

:FETCh:FMAudio:FM:AUDio:TIME:TRACe:RIGHT:BINary

:FETCh:FMAudio:FM:AUDio:FREQuency:TRACe:LEFT:BINary

:FETCh:FMAudio:FM:AUDio:FREQuency:TRACe:RIGHT:BINary

**Figure 3.3.3-3** Measurement Settings Pane (Graph FM Demod-AF)

TX-FM	
FM Frequency/Level	
Carrier Frequency(MHz)	:FETCh:FMAudio:FM:RF
Frequency Error(Hz)	
Carrier Level(dBm)	

Figure 3.3.3-4 FM Frequency/Level Measurement Results


Occupied Bandwidth	
Occupied Bandwidth(kHz)	:FETCh:FMAudio:FM:OBW
Upper Frequency	:FETCh:FMAudio:FM:OBW:FREQUENCY
Lower Frequency	
Center(Upper + Lower)/2	

Figure 3.3.3-5 Occupied Bandwidth Measurement Results

Modulation Analysis	
FM Deviation +P	:FETCh:FMAudio:FM:DEMod:BOTH:DEViation
FM Deviation -P	
FM Deviation (P+P)/2	
FM Deviation RMS	
Left-Channel Deviation +P	:FETCh:FMAudio:FM:DEMod:LEFT:DEViation
Left-Channel Deviation -P	
Left-Channel Deviation (P+P)/2	
Left-Channel Deviation RMS	
Right-Channel Deviation +P	:FETCh:FMAudio:FM:DEMod:RIGHT:DEViation
Right-Channel Deviation -P	
Right-Channel Deviation (P+P)/2	
Right-Channel Deviation RMS	

Figure 3.3.3-6 Modulation Analysis Measurement Results



**Figure 3.3.3-7** RDS Measurement Results

RDS measurement results are displayed when RDS Analysis is set to **On**.

:FETCh:FMAudio:FM:DEMod:LEFT:AF		:FETCh:FMAudio:FM:DEMod:CROSstalk	
Demodulate-AF Frequency/Level	Frequency(Hz)	Level(Hz)	Cross Talk(dB)
Left-Channel Audio Tone 1	---	---	---
Left-Channel Audio Tone 2	---	---	---
Left-Channel Audio Tone 3	---	---	---
Left-Channel Audio Tone 4	---	---	---
Left-Channel Audio Tone 5	---	---	---
Left-Channel Audio Tone 6	---	---	---
Left-Channel Audio Tone 7	---	---	---
Left-Channel Audio Tone 8	---	---	---
Left-Channel Audio Tone 9	---	---	---
Left-Channel Audio Tone 10	---	---	---
Left-Channel Audio Tone 11	---	---	---
Left-Channel Audio Tone 12	---	---	---
Right-Channel Audio Tone 1	---	---	---
Right-Channel Audio Tone 2	---	---	---
Right-Channel Audio Tone 3	---	---	---
Right-Channel Audio Tone 4	---	---	---
Right-Channel Audio Tone 5	---	---	---
Right-Channel Audio Tone 6	---	---	---
Right-Channel Audio Tone 7	---	---	---
Right-Channel Audio Tone 8	---	---	---
Right-Channel Audio Tone 9	---	---	---
Right-Channel Audio Tone 10	---	---	---
Right-Channel Audio Tone 11	---	---	---
Right-Channel Audio Tone 12	---	---	---

:FETCh:FMAudio:FM:DEMod:RIGHT:AF

**Figure 3.3.3-8** Demodulate-AF Frequency/Level Measurement Results

The measurement results of the screen below are displayed when Audio Modulation is set to [Stereo]. When Audio Modulation is set to [Mono], “---” is displayed.

Right-Channel Audio Tone 1 to Right-Channel Audio Tone 12, Cross Talk

Demodulate-AF SINAD	
Left-Channel SNR(dB)	:FETCh:FMAudio:FM:DEMod:LEFT:ANALysis
Left-Channel THD(dB)	
Left-Channel THD(%)	
Left-Channel THD+N(dB)	
Left-Channel THD+N(%)	
Left-Channel SINAD(dB)	
Right-Channel SNR(dB)	:FETCh:FMAudio:FM:DEMod:RIGHT:ANALysis
Right-Channel THD(dB)	
Right-Channel THD(%)	
Right-Channel THD+N(dB)	
Right-Channel THD+N(%)	
Right-Channel SINAD(dB)	
19kHz Pilot Signal Frequency Error(Hz)	:FETCh:FMAudio:FM:DEMod:PILot
19kHz Pilot Signal Level(Hz)	

**Figure 3.3.3-9** Demodulate-AF SINAD Measurement Results

The measurement results below are displayed when Audio Modulation is set to [Stereo].

When Audio Modulation is set to [Mono], “---” is displayed.

Right-Channel SNR (dB), Right-Channel THD (dB), Right-Channel THD (%),  
 Right-Channel THD+N (dB), Right-Channel THD+N (%), Right-Channel SINAD (%),  
 19kHz Pilot Signal Frequency Error (Hz), 19kHz Pilot Signal Level (Hz)


## 3.4 FM Receiver Measurement

This section explains how to perform FM receiver measurement.

### 3.4.1 Setting conditions

The figure below is the settings pane for FM receiver measurement.


Change the parameter values or selections by clicking ▲/▼.



**Figure 3.4.1-1** FM Transmitter Measurement Settings Pane

### 3.4.2 Measurement and results

To perform measurement:

1. Click the Open/Close button to open [Common Setting] and set DUT Type to [FM Receiver].
2. Set the parameters of [Common Setting].
3. Click the Open/Close button of [RX-FM], and set the parameters from [Level] to [AM Frequency].  
Set the [Output] and [Modulation] to On.
4. When [FM Signal Generation] is set to [Off], click the Open/Close button to open [Vector Signal Generator] and set waveform pattern. For setting details, refer to Section 3.4.4 “Setting Waveform Pattern.”  
Proceed to Step 7 after setting the waveform pattern.
5. When [FM Signal Generation] is set to [On], set [Audio Modulation].
6. Click [FM AF Tone Setting Window] to set tone signals. Refer to Section 3.4.3 “Setting tone signals”.
7. Click the Measurement Start button . The parameters are sent to the hardware, and the MT8870A outputs the RF signal.

### 3.4.3 Setting Tone Signals

Perform the following steps to set tone signals to output.

1. Click [FM AF Tone Setting Window] to open the FM AF Tone Setting window.
2. Set [On/Off], [Frequency(Hz)], and [Deviation(Hz)] for Left-Channel 1 to 8 individually. The text box color turns into red when the input value is out of the setting range. Check the setting range and re-input the value within the range.
3. When [Audio Modulation] is set to [Stereo], set the parameters for Right-Channels as in Step 2.
4. Click [OK] to save the settings and close the FM AF Tone Setting window. Click [Cancel] to close the window without saving the settings.

**RX-FM : FM AF Tone Setting**

**Left-Channel**

No.	On/Off	Frequency(Hz)	Deviation(Hz)
1	Off	1000.0	500.1
2	On	1000.0	300.1
3	On	1000.0	400.1
4	On	400.1	900.1
5	Off	19.0	600.1
6	Off	500.1	500.1
7	Off	100.1	400.1
8	Off	800.1	700.1

**Right-Channel**

No.	On/Off	Frequency(Hz)	Deviation(Hz)
1	On	400.1	300.1
2	On	1000.0	2000000.0
3	Off	500.1	500.1
4	On	20000.0	700.1
5	On	20000.0	400.1
6	On	1000.0	900.1
7	Off	600.1	200.1
8	Off	400.1	500.1


OK Cancel

**Figure 3.4.3-1** Example of RX-FM : FM AF Tone Setting

### 3.4.4 Setting waveform pattern

Set the waveform pattern of the RF signal in the procedure below.

1. Click the **Vector Signal Generator** button to open the dialog.
2. Click **Refresh waveform file list** to update the file list before file loading.
3. Click the **Select waveform to load** button to specify the file.
4. Click **Load waveform into ARB memory** to load the file.
5. Click the **Select waveform** button to select the waveform package.
6. Click the **Select pattern from waveform** button to select the waveform pattern.
7. Click the **Set pattern** button to set the selected waveform pattern as the VSG modulation pattern.



**Figure 3.4.4-1** Vector Signal Generator Setting

The file set by **Select waveform to load** button is loaded to the memory in the MU887000A by clicking **Load waveform into ARB memory** button.

While loading the file, the status indication lamp 2 of the MU887000A blinks in green.

When the loading error occurs, the status indication lamp 2 of the MU887000A is lit in red.

In that case, query the cause by using :SOURce:GPRF:GENerator:ARB:FILE:LOAD? command.

For description of the command, refer to Chapter 5 “SCPI Command” in *the MU887000A TRX Test Module Operation Manual*.


Following parameters are sent to MU887000A by clicking **Set pattern** button.

**Select waveform, Select pattern from waveform**

### 3.4.5 Related SCPI commands

The following figure shows the remote control commands of the MX887070A FM/Audio TRX Measurement and the corresponding fields on the pane.

For details of the commands, refer to Chapter 3 “SCPI Command Reference” in *the MX887070A FM/Audio TRX Measurement Operation Manual* and Chapter 5 “SCPI Command” in *the MU887000A TRX Test Module Operation Manual*.



**Figure 3.4.5-1** Measurement Settings Pane






Figure 3.4.5-2 Tone Setting Window





Figure 3.4.5-3 Measurement Settings Pane (Vector Signal Generator)

## 3.5 Audio Signal Measurement

This section explains how to perform audio signal measurement.

### 3.5.1 Setting conditions







The figure below is the settings pane for audio signal measurement. Change the parameter values or selections by clicking ▲/▼.




**Figure 3.5.1-1** Audio Signal Measurement Settings Pane

### 3.5.2 Measurement and results

To perform measurement:

1. Click the Open/Close button to open [Common Setting] and set DUT Type to [FM Receiver].
2. Set the parameters of [Common Setting].
3. Click the Open/Close button of [TX-Audio], and set the parameters from [Input Range] to [Audio Modulation].
4. Click the Open/Close button to open [Left-Channel] and set the parameters.
5. When [Audio Modulation] is set to [Stereo], click the Open/Close button to open [Right-Channel] and set the parameters.
6. When [Analog] is set to [Audio Interface] in [Common Setting], click the Open/Close button to open [Graph: Audio AF (Analog)].
7. When [Digital] is set to [Audio Interface] in [Common Setting], click the Open/Close button to open [Graph: Audio AF (Digital)].
8. Enable the check icon  of [Time Domain (Left) ], [Time Domain (Right) ], [Spectrum Monitor (Left)], or [Spectrum Monitor (Right)] .  
Additionally, set the parameters from [Time Domain X-Axis Range(ms)] to [Spectrum Monitor Y-Axis Scale (Right) (dBV)] or [Spectrum Monitor Y-Axis Scale (Right) (dBFS)].
9. Click [Display Results] to display [FM Audio] tab.
10. When [Audio Interface] of [Common Setting] is set to [Analog], click the Open/Close button to open [Display Results Settings] and select the check icon  of [TX-Audio(Analog)].
11. When [Audio Interface] of [Common Setting] is set to [Digital], click the Open/Close button to open [Display Results Settings] and select the check icon  of [TX-Audio(Digital)].
12. Click the Measurement Start button  to send the parameters to the hardware.
13. When the measurement ends, numerical data is displayed in TX-Audio(Analog) or TX-Audio(Digital) in [FM Audio] tab.
14. Click the graph icon  on the next pane to display the graph.  
[Time Domain (Left) ], [Time Domain (Right) ], [Spectrum Monitor (Left)], or [Spectrum Monitor (Right)]
15. To display the marker positions and values, click  button in [Makers] sub window on the top-right corner. When dragging the markers, the positions are shown by values in the sub window.




**Figure 3.5.2-1** Spectrum Monitor Graph


### 3.5.3 Related SCPI commands

The following figure shows the remote control commands of the MX887070A FM/Audio TRX Measurement and the corresponding fields on the pane.


For details of the commands, refer to Chapter 3 “SCPI Command Reference” in *the MX887070A FM/Audio TRX Measurement Operation Manual*.



**Figure 3.5.3-1** Measurement Settings Pane



**Figure 3.5.3-2** Measurement Settings Pane (Graph: Audio AF (Analog))



**Figure 3.5.3-3** Measurement Settings Pane (Graph: Audio AF (Digital))




Figure 3.5.3-4 AF Total Level Measurement Results

:FETCh:FMAudio:AF:AUDio:LEFT:AF      :FETCh:FMAudio:AF:AUDio:CROSstalk

AF Frequency/Level	Frequency(Hz)	Level(mv)	Cross Talk(dB)
Left-Channel Audio Tone 1	-7.00	17.00	-37.00
Left-Channel Audio Tone 2	-0.50	-0.54	-2.00
Left-Channel Audio Tone 3	-76.00	-0.30	-65.00
Left-Channel Audio Tone 4	-46.00	-0.68	-1.04
Left-Channel Audio Tone 5	94.00	-7.00	-5.00
Left-Channel Audio Tone 6	35.00	-65.00	-27.00
Left-Channel Audio Tone 7	-0.24	1.86	81.00
Left-Channel Audio Tone 8	66.00	29.00	-90.00
Left-Channel Audio Tone 9	-44.00	32.00	-16.00
Left-Channel Audio Tone 10	11.00	88.00	-12.00
Left-Channel Audio Tone 11	-95.00	-39.00	-32.00
Left-Channel Audio Tone 12	-51.00	-78.00	63.00
Right-Channel Audio Tone 1	0.70	1.06	-1.18
Right-Channel Audio Tone 2	-0.52	-30.00	-73.00
Right-Channel Audio Tone 3	-3.00	-6.00	-0.92
Right-Channel Audio Tone 4	71.00	22.00	-1.94
Right-Channel Audio Tone 5	88.00	-80.00	-0.30
Right-Channel Audio Tone 6	25.00	52.00	72.00
Right-Channel Audio Tone 7	50.00	0.36	25.00
Right-Channel Audio Tone 8	-1.66	-61.00	-36.00
Right-Channel Audio Tone 9	1.96	-40.00	28.00
Right-Channel Audio Tone 10	57.00	-20.00	5.00
Right-Channel Audio Tone 11	61.00	17.00	-13.00
Right-Channel Audio Tone 12	9.00	-37.00	-85.00

:FETCh:FMAudio:AF:AUDio:RIGHT:AF

Figure 3.5.3-5 AF Frequency/Level Measurement Results

The measurement results of the screen below are displayed when Audio Modulation is set to [Stereo].

When Audio Modulation is set to [Mono], “---” is displayed.

Right-Channel Audio Tone 1 to Right-Channel Audio Tone 12, Cross Talk

AF SINAD	
Left-Channel SNR(dB)	:FETCh:FMAudio:AF:AUDio:LEFT:ANALysis
Left-Channel THD(dB)	
Left-Channel THD(%)	
Left-Channel THD+N(dB)	
Left-Channel THD+N(%)	
Left-Channel SINAD(dB)	:FETCh:FMAudio:AF:AUDio:RIGHT:ANALysis
Right-Channel SNR(dB)	
Right-Channel THD(dB)	
Right-Channel THD(%)	
Right-Channel THD+N(dB)	
Right-Channel THD+N(%)	
Right-Channel SINAD(dB)	

**Figure 3.5.3-6** AF SINAD Measurement Results

The measurement results below are displayed when Audio Modulation is set to [Stereo].

When Audio Modulation is set to [Mono], “---” is displayed.

Right-Channel SNR (dB), Right-Channel THD (dB), Right-Channel THD (%),

Right-Channel THD+N (dB), Right-Channel THD+N (%), Right-Channel SINAD (%)




## 3.6 Audio Signal Transmission

This section explains how to send audio signal.

### 3.6.1 Setting conditions

The figure below is the settings pane for audio signal transmission. Change the parameter values or selections by clicking ▲/▼.




**Figure 3.6.1-1** Audio Signal Transmission Settings Pane

---

### 3.6.2 Measurement and results

To perform measurement:

1. Click the Open/Close button to open [Common Setting] and set DUT Type to [FM Transmitter].
2. Set the parameters of [Common Setting].
3. When [Analog] is set to [Audio Interface] in [Common Setting], click the Open/Close button to open [RX-Audio(Analog)].
4. When [Digital] is set to [Audio Interface] in [Common Setting], click the Open/Close button to open [RX-Audio(Digital)].
5. Click [AF Tone Setting Window] to set tone signals. Refer to Section 3.6.3 “Setting tone signals”.
6. Click the Measurement Start button  to send the parameters to the hardware. The MT8870A outputs the audio signal.

### 3.6.3 Setting Tone Signals

Perform the following steps to set tone signals to output.

1. Click [AF Tone Setting Window] to open the AF Tone Setting window.
2. Set [On/Off], [Frequency(Hz)], [Level(mVp)] (Analog), and [Level (dBFS)] (Digital) for Left-Channel 1 to 8 individually. The text box color turns into red when the input value is out of the setting range. Check the setting range and re-input the value within the range.
3. Set the parameters for Right-Channels as in Step 2.
4. Click [OK] to save the settings and close the AF Tone Setting window. Click [Cancel] to close the window without saving the settings.

**RX-Audio(Analog) : AF Tone Setting**

**Left-Channel**

No.	On/Off	Frequency(Hz)	Level(mVp)
1	Off	0.10	401.00
2	Off	600.10	601.00
3	Off	600.10	1.00
4	Off	800.10	101.00
5	Off	500.10	301.00
6	Off	400.10	701.00
7	Off	600.10	1.00
8	Off	800.10	901.00

**Right-Channel**

No.	On/Off	Frequency(Hz)	Level(mVp)
1	Off	900.10	401.00
2	Off	300.10	801.00
3	Off	700.10	501.00
4	Off	400.10	501.00
5	Off	200.10	201.00
6	Off	800.10	801.00
7	Off	800.10	401.00
8	On	800.10	201.00


OK Cancel

**Figure 3.6.3-1** Example of RX-Audio(Analog) : AF Tone Setting


### 3.6.4 Related SCPI commands

The following figure shows the remote control commands of the MX887070A FM/Audio TRX Measurement and the corresponding fields on the pane.

For details of the commands, refer to Chapter 3 “SCPI Command Reference” in *the MX887070A FM/Audio TRX Measurement Operation Manual*.



**Figure 3.6.4-1** Measurement Settings Pane (RX-Audio (Analog))



**Figure 3.6.4-2** Measurement Settings Pane (RX-Audio (Digital))

When the tone is over the level, Tone Signal Over Flow is displayed in AF Tone Level Status.




Figure 3.6.4-3 Tone Setting Window (RX-Audio (Analog))




Figure 3.6.4-4 Tone Setting Window (RX-Audio (Digital))

